

PS Series

CAT.NO.	DESCRIPTION
P301	1 gang 1 way switch
P302	1 gang 2 way switch
P303	2 gang 1 way switch
P304	2 gang 2 way switch
P305	3 gang 1 way switch
P306	3 gang 2 way switch
P405	1 gang 13amp S.P switch socket
P409	1 gang 13amp DP switch socket
P407	1 gang 13amp S.P switch socket W/neon
P406	2 gang 13amp S.P switch socket
P410	2 gang 13amp DP switch socket
P408	2 gang 13amp S.P switch socket W/neon
P429	1 gang 15amp switch socket
P431	1 gang 15amp switch socket W/neon

